Aluminaide AMD Treatment Project

Water Sample Locations

Legend

- Huling Run Aluminade Discharge Passive Wetland
- Inflow Sample Location
- Outflow Sample Location

Huling Run

200 ft

Tributary

Outflow Sample Location

Huling Run Aluminade Discharge Passive Wetland Inflow Sample Location

Google Earth

© 2018 Google